



USER INFORMATION

When plugging the ZAGGsparq into the wall, the bottom LED will light up when the ZAGGsparq's battery reaches 10% which can take up to 30 minutes if the battery is completely depleted. The remaining LED's will light up as the ZAGGsparq battery charges.

Before initial use, charge for 9 hours. This is required for a full battery charge.

To check the power level, press the button below the LED's.

LED POWER LEVELS:

4 LED's = 80 - 100%

3 LED's = 60 - 79%

2 LED's = 40 - 59%

1 LED = 20 - 39%

0 LED's = below 20%

CAUTION:

Do not store below 40° F or above 90°

Keep away from flames

Avoid impact with ground

The ZAGGsparq 2.0 features two USB charging ports: Optimized and General. ZAGG recommends always trying the Optimized port first. If your device does not charge through the Optimized port, use the General port.

Optimized port: The top USB port is designed for most smartphones and other devices which are capable of taking an optimized charge, including the Apple® iPad®, iPhone®, and iPod® family of products. Some devices will not charge through the Optimized port.

General port: The bottom USB port uses standard USB specifications and will charge devices which do not utilize the Optimized USB charging specification.

The ZAGGsparq can charge two devices simultaneously. However, when charging a device that draws a significant amount of power, such as the Apple iPad, you may not be able to use both USB ports at the same time. If two high-power drawing devices are connected, it may deactivate the ZAGGsparq. If this occurs, simply disconnect one of the devices. You may also have to plug the ZAGGsparq into an outlet to reset it.

Power Source: AC 100-240 V @ 50/60 Hz
Fixed output: 2000 mAh
Powerful 6,000 mAh lithium polymer

